

# WOOD PLANK



collection	species
TOWNE	EUROPEAN OAK
<b>COLOGNE</b>	
item	

THICKNESS	WIDTH	SURFACE FINISH
13/16 <sup>TH</sup>	7"-1/2	MATT URETHANE

TEXTURE	TENON	BEVELED	WEAR LAYER
BRUSHED	T&G	0.5 MM	6MM

## ACCLIMATION

The wood floor needs to be acclimated on site for 7 - 14 days depending upon the moisture content of the planks, subfloor and the environment it will be performing in. ■ See the installation manual for more details.

## INSTALLATION & MAINTENANCE

Dry cleaning is the best way to clean wood floors, rather than wet cleaning. Vacuum regularly and occasionally use a damp, well wrung-out cloth mop with BONA Floor cleaner. Floor should dry within one minute if used proper amount of cleaner.

■ See the installation manual for more details.

RESIDENTIAL  
**15**  
 YEARS  
**5**  
 COMMERCIAL  
**WARRANTY**

**INSTALLATION**



2301 Defoor Hills RD NW, Atlanta, GA 30318  
 404-941-7420

