

WOOD PLANK



collection	species
TOWNE	EUROPEAN OAK
METZ	
item	

THICKNESS	WIDTH	SURFACE FINISH
13/16 TH	7"-1/2	MATT URETHANE

TEXTURE	TENON	BEVELED	WEAR LAYER
SMOOTH	T&G	0.5 MM	6MM

ACCLIMATION

The wood floor needs to be acclimated on site for 7 – 14 days depending upon the moisture content of the planks, subfloor and the environment it will be performing in. ■ See the installation manual for more details.

INSTALLATION & MAINTENANCE

Dry cleaning is the best way to clean wood floors, rather than wet cleaning. Vacuum regularly and occasionally use a damp, well wrung-out cloth mop with BONA Floor cleaner. Floor should dry within one minute if used proper amount of cleaner.

■ See the installation manual for more details.

RESIDENTIAL
15
 YEARS
5
 COMMERCIAL
WARRANTY

INSTALLATION



2301 Defoor Hills RD NW, Atlanta, GA 30318
 404-941-7420