

WOOD PLANK



Engineered
Wood



Plank



Radiant
Floor



Tongue
& Groove



Interior



Residential

collection	species
CASSETTA	EUROPEAN OAK
MODENA	
item	

 THICKNESS	 WIDTH	 SURFACE FINISH
5/8 TH	6"	MATT URETHANE

TEXTURE	TENON	 BEVELED	 WEAR LAYER
BRUSHED	T&G	0.5MM	3MM

INSTALLATION & MAINTENANCE

Dry cleaning is the best way to clean wood floors, rather than wet cleaning. Vacuum regularly and occasionally use a damp, well wrung-out cloth mop with BONA Floor cleaner. Floor should dry within one minute if used proper amount of cleaner.

■ See the installation manual for more details.

ACCLIMATION

The wood floor needs to be acclimated on site for 7 - 14 days depending upon the moisture content of the planks, subfloor and the environment it will be performing in. See the installation manual for more details.



2301 Defoor Hills RD NW,
Atlanta, GA 30318
404-941-7420

ciotlegno.com

